


To start using the tryout key, loosen the two screws on the handle and pull out the 'tip shaft' and "spacer tube"



On the tip shaft you will find 4 of each tumblers:


- 4 x number 1 tumblers
- 4 x number 2 tumblers
- 4 x number 3 tumblers
- 4 x number 4 tumblers

number 1


number 2

number 3

number 4



Loaded tryout key to code:



Remove all the tumblers and load the tryout key with the new code.

The following example is code:

The key code is always read from the shoulder

So you would load:

onto the tip shaft

When you have loaded the tumblers, replace the spacer tube and slide into the handle and lock into place by tightening BOTH screws.

YOU SHOULD NOW HAVE A WORKING KEY

Note: Before using it may be necessary to run a fine warding file over the tip to remove any excess casting metal and to make the tool easier to insert into the lock.